


Installation Manual




Components list





Pre-installation


TOOLS REQUIRED



HARDWARE INCLUDED

A  (x1)	B  (x1)  ST4.8x25(x2)
	C  (x1)  ST4.8x38(x2)  Ø8 (x2)


Door preparation




Installation

1A Mark the hole position by pencil.(Door Width ≤ 850mm)

C



(x1)




1B Mark the hole position by pencil.(850mm<Door Width≤1600mm)


C




(x1)




2 Drill holes.




3 Fixing top pivot and bottom plate accordingly.




4 Loosen the screws to make pin retract.







5 Fasten the screws to make pin pot out inside the top pivot.



6 Loosen the screw in the slotted hole to ensure door is parallel with wall and fasten both screws.




7 Remove the hinge and adjust the opening and closing door force if necessary.



8 Mount a handle

A



(x1)

